

centormail Teleset Re-Crediting Instructions

Overview

Teleset re-crediting is the loading of postage from your FP Teleset account onto your franking machine. This involves the machine dialling up to the FP Teleset server via your analogue telephone line. The franking machine then requests the amount you have specified and transfers the funds securely to your centormail franking machine.

Re-crediting requirements


As mentioned above, you require an analogue telephone line.

You must have funds available on your FP Teleset account ready for downloading.

You must download your postage funds in £10 increments. i.e. £10, £20, £50, £100.


(Re-crediting of £56 for example is not possible)

The minimum amount for download is £10.



Loading postage

centormail has to be connected to a phone line for the duration of the loading procedure. Make sure that the dialing parameters of the modem and the Teleset Data Center (TDC) phone number are correctly set.

- Press the  key.
- Press **TELESET** to initiate the transfer procedure.
- Retain the displayed amount.

or

Press **CHANGE** to call up the menu for changing amounts. Type in the desired amount.



centormail checks if the amount you entered can be loaded.

Note that centormail rejects impermissible amounts – in that case, a message is issued to inform you.

- Press **LOAD** to confirm.

centormail displays the set amount for checking purposes.

To load the displayed amount:

- Confirm the security prompt by pressing **YES**.

centormail establishes a connection to the TDC. The loading procedure is performed automatically. You can monitor the progress in the display. Please stand by. Data exchange takes some time.

The new ascending value (R1) is displayed when loading is completed.

- Press **REPORT** to view and print the loading report.
- Press **FINISH** to return to the home menu.